

Precise, Rapid and Scalable Size Selection of Nanoparticle Populations

Contact

Brian Wright
Auburn University
Office of Technology Transfer
334-844-4977
brian.wright@auburn.edu
<http://ott.auburn.edu/>
Reference: Size Selection

Inventors

Dr. Chris Roberts
Department Chair & Professor
Department of Chemical Engineering

Dr. Chandler McLeod
Ph.D. Graduate
Department of Chemical Engineering

Madhu Anand
Ph.D. Graduate
Department of Chemical Engineering

Steven R. Saunders
Doctoral Candidate
Department of Chemical Engineering

Reference

McLeod, M. C.; Anand, M.; Kitchens, C. L.; Roberts, C. B. *Nano Lett.*; (Letter); 2005; 5(3); 461-465. (pdf)

Licensing

This technology is available for exclusive or non-exclusive licensing

[Click here for a listing of Auburn's available physical science technologies](#)



Auburn University is an equal opportunity educational institution/employer.

Overview

Auburn University seeks a licensee for a method for the precise and rapid size selection of nanoparticles from a polydisperse population. When compared to existing processes, Auburn's CO₂-based process is faster, less expensive, cleaner, more precise, tunable and scalable. This technology has potential applications throughout the nanotechnology industry, including optics and imaging.

Advantages

- Significantly reduces time needed for a size fractionation compared to centrifugation
- Reduces expense and increases throughput (as compared to chromatographic methods)
- Narrows particle distributions as compared with existing methods
- Allows for mean particle size and polydispersity to be predetermined by simply choosing the proper CO₂ pressurization
- Reduces operating costs and environmental impact through use of CO₂ as the antisolvent
- Reduces post-processing time and costs through use of CO₂, allowing simple particle cleaning and solvent/antisolvent recycling
- Allows easy and precise separation of various nanostructures, including nanorods or quantum dots

Description

This method for precise, rapid and improved separation of nanoparticles by size relies on a solvent/antisolvent method that uses a gaseous antisolvent (e.g., CO₂) to create a tunable gas-expanded liquid. Pressurized gaseous CO₂ is placed over a nanoparticle solution. By changing the pressure of CO₂, the resulting fraction of liquid CO₂ in the solution can be increased or decreased. Given that particle dispersibility is a function of CO₂ concentration in the liquid, particles of any given target size can be made to precipitate by simply manipulating the CO₂ pressure. Multiple monodisperse particle populations can be rapidly fractionated by adjusting only the CO₂ pressure and the liquid location, thereby eliminating the difficulties associated with other methods that are time and solvent intensive, expensive and/or have limited throughput.

Status

- A companion technology exists that uses a similar methodology to deposit nanoparticles as dense films with more uniformity, less processing and less cost than existing methods
- US (20070243716) and EU applications have been filed; additional non-provisional filings are anticipated
- This invention have been successfully verified by laboratory experiment with various ligand-coated metallic and semiconductor nanoparticles
- A scalable prototype system has been created and tested (see figure)

